



OUTLAW INDUSTRIES

01/01/2020

OUTLAW AG SERIES TURNSTILES

3475 South Calhan Hwy. Calhan Colorado 80808 PH. 1-800-590-0464

Maintenance For the AG Series Turnstiles

- Annually
 - Remove The lid from the header
 - Clean out the header of dust and debris
 - Take out center shaft by lifting it out of the top of the locking mechanism (you may need a pair of channel locks to grip the shaft).
 - Add grease when reinserting the shaft, for ease of future maintance.
 - Lift the center rotor off of the bearing, inspect bearing, regrease with red grease or replace if necessary. Make sure that the rotor is oriented properly with the arms facing the middle / center of the cage. If replacement is necessary the bottom bearing part number AGRB10
 - Test electrical function by triggering turnstile to unlock in each direction
 - Shut off the equipment breaker in the header of the turnstile, make sure that fail-open and fail-close are functionaly properly.
 - If your turnstile is equipped with lights, verify that all directional lights are working properly, replace bulbs or module as necessary

OUTLAW INDUSTRIES
3475 S. CALHAN HWY
CALHAN, CO 80808
SALES@OUTLAWINDUSTRIES.CO

JESSE JAMES: 719-427-2233
JESSE JAMES JR: 719-427-2241
SHOP: 1-800-590-0464